



PROSHOWER PROFILE




SATINED STAINLESS STEEL AISI 304 / 1.4301 - V2A

PROSHOWER PROFILE is a profile for floor level showers in stainless steel for the protection of the floor edges and as decoration of the screed visible side. The profile has a 2% slope. Its specific shape makes it an easy to lay profile to be used with all kind of floor.


PSHWPACS... SX




PSHWPACS... DX



PSHWPACS ... DX



EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



SATINED STAINLESS STEEL AISI 304/1.4301-V2A - RIGHT

degreased and passivated - thermo packed - Pack. 1 Pc

Article	H mm	H1 mm	H2 mm	L cm	€/Pc
PSHWPACS 1010DX	10	11	28	100	75,25
PSHWPACS 1015DX	10	11	38	150	91,42
PSHWPACS 1020DX	10	11	48	200	111,88
PSHWPACS 12510DX	12,5	13,5	30	100	78,98
PSHWPACS 12515DX	12,5	13,5	40	150	95,15
PSHWPACS 12520DX	12,5	13,5	50	200	115,61

SATINED STAINLESS STEEL AISI 304/1.4301-V2A - LEFT

degreased and passivated - thermo packed - Pack. 1 Pc

Article	H mm	H1 mm	H2 mm	L cm	€/Pc
PSHWPACS 1010SX	10	11	28	100	75,25
PSHWPACS 1015SX	10	11	38	150	91,42
PSHWPACS 1020SX	10	11	48	200	111,88
PSHWPACS 12510SX	12,5	13,5	30	100	78,98
PSHWPACS 12515SX	12,5	13,5	40	150	95,15
PSHWPACS 12520SX	12,5	13,5	50	200	115,61

1. Choose "PROSHOWER PROFILE" according to the desired length.
2. Cut "PROSHOWER PROFILE" to the desired length and apply the adhesive on the support where the profile will be laid.
3. Press the anchoring flange of "PROJOLLY SQUARE" into the adhesive.
4. Lay the tiles, aligning them with the profile leaving a 2 mm joint. Remove immediately all remains of adhesive from the surface of the profile.
5. Fill the joints between the profile and the tiles with grout, in order to avoid water stagnation. Remove immediately all the remains of grout from the surface of the profile.
6. Insert the sheet of glass and seal.